

BFAF - Bare Fiber Adapters

Description:

The BFAF Adapter introduces new innovated series of Bare Fiber Adapters. It is designed to be used for temporarily connection of unterminated fibers to meet test, service and communications requirements. Adapters are available with FC and SC connectors.



Features:

- Simply strip and cleave your fiber and insert into the Bare Fiber Adapter
- Broken fibers are removed with piano wire allowing hundreds of insertions
- Accommodates 125 μm clad fiber with Insertion loss < 1 dB

Specifications:



BFAF-PC-Z-1



BFAF-SC-Z-1

Application:

- Quick terminating fibers
- Cable checking
- Fiber optic component production

Ordering code:

BFAF - AA - X - X

XX - Connector Type

SC	SC
PC	FC
other	- on request

Diameter of the Ferrule

1	125 μm
2	126 μm
3	127 μm

Z	zirconia ferrule material
----------	---------------------------